Startup Procedures

Congratulations on your purchase of a Comfortbilt Pellet Stove! We're sure you're going to enjoy you new stove for many years to come. After the piping is installed on your new stove, the next steps are as follows:

1. Place Pellets into Hopper Tank
2. Plug in Power Cord
3. Turn on Main Switch on Back
4. Remove Cardboard from Burn Area
5. Mount Control Panel on Top
6. Plug in Gray Flat Cord into Control Panel
7. Push On/Off button (Top Left on Control Panel)
8. Look for all Indicators to be Displayed
9. Display Screen will Display "Ignite 1"
10. Top Right will Display "Manual, Temp, or Weekly Settings"
11. Toward the end of Ignite 2 Cycle, Smoke will begin to appear in Burn Pot
12. After Fire is established 4-5 minutes the Room Blower Fan will come on automatically
13. Temperature Probe is located on the back
14. To set Data Changes-Push and Hold in the Left Arrow near Up/Down Buttons
15. Select Desired Menu to Change- After Selection Choices are changed, Push Arrow Again
16. After Changes are made – Push the "U-Turn" Button on Top Right
17. Clean Burning Pot after 2 Days
18. Vacuum or Empty Ash Pan Monthly

Remember, when choosing Pellets, look for an 8200 or higher BTU Rating with .05 or less Ash and .05 Fines – Can be 100% Hardwood or 80/20% Soft/Hard Mix.

If you have any questions or concerns please feel free to contact us at (919) 388-7614 OR (919) 388-7615

We thank you for your purchase.

Sincerely,

The ComfortBilt Team